

includes both supply and return ducts. For areas other than attics, the values are R-6 and R-4.2. Energy losses are less in smaller ducts, therefore the R-value of the insulation is lower for ducts less than 3 inches in diameter.

The exception addresses the fact that ductwork in the thermal envelope is already protected from energy loss by virtue of being in the thermal envelope.

R403.3.2 Sealing (Mandatory). Ducts, air handlers and filter boxes shall be sealed. Joints and seams shall comply with either the *International Mechanical Code* or *International Residential Code*, as applicable.

Exceptions:

1. Air-impermeable spray foam products shall be permitted to be applied without additional joint seals.
2. For ducts having a static pressure classification of less than 2 inches of water column (500 Pa), additional closure systems shall not be required for continuously welded joints and seams, and locking-type joints and seams of other than the snap-lock and button-lock types.

❖ Ducts must be sealed in accordance with the duct sealing requirements of either the IMC or the code. Joints and seams that fail in a duct system can result in increased energy use because the conditioned air will be delivered to an unconditioned space or to a building space where it is not needed, such as a wall or floor assembly, crawl space or attic, instead of to a room or area inside the conditioned envelope. Return-air ductwork installed in basements or concealed building spaces may conduct chemicals or other products that produce potentially harmful fumes. Because the return air operates under negative pressure, any leaks could draw fumes, moisture, soil gases or odors from the surrounding area and direct them into the house. Therefore, sealing of return-air ductwork is also a requirement.

Duct tightness must be checked by leakage testing of the ducts at the end of construction or at the time of rough in. The pass/fail criteria for leakage rate is more stringent if the rough-in test time is chosen. This is simply because it is probably that some of the ductwork will be disturbed during subsequent construction and, therefore, have a higher leakage rate than what was tested.

R403.3.2.1 Sealed air handler. Air handlers shall have a manufacturer's designation for an air leakage of no more than 2 percent of the design air flow rate when tested in accordance with ASHRAE 193.

❖ This section of the code requires that air handlers have a manufacturer's designation for an air leakage of not more than 2 percent of the design flow rate when tested in accordance with ASHRAE 193. Energy conservation measures in the air-conditioning industry have driven the manufacturers of systems

and components to establish compliance with leakage limits in ducts and air-handling units. The standards set by the American Society of Heating, Refrigerating and Air-conditioning Engineers (ASHRAE) form the basis for testing. Establishing an air-handler leakage rate, given the availability of a uniform test procedure, is prudent since any leakage in the air-handling unit contributes to waste of energy. The magnitude of leakage has a direct bearing on energy use and indoor air quality.

R403.3.3 Duct testing (Mandatory). Ducts shall be pressure tested to determine air leakage by one of the following methods:

1. Rough-in test: Total leakage shall be measured with a pressure differential of 0.1 inch w.g. (25 Pa) across the system, including the manufacturer's air handler enclosure if installed at the time of the test. All registers shall be taped or otherwise sealed during the test.
2. Postconstruction test: Total leakage shall be measured with a pressure differential of 0.1 inch w.g. (25 Pa) across the entire system, including the manufacturer's air handler enclosure. Registers shall be taped or otherwise sealed during the test.

★ **Exception:** A duct air leakage test shall not be required where the ducts and air handlers are located entirely within the building thermal envelope.

A written report of the results of the test shall be signed by the party conducting the test and provided to the code official. ←

❖ Duct tightness must be checked by leakage testing at the end of construction or at the time of rough-in. This affords some flexibility to the builder. The test at the end of construction, if failed, could be more difficult to correct. However, the test after rough-in is more stringent as noted in the commentary to Section R403.3.4.

R403.3.4 Duct leakage (Prescriptive). The total leakage of the ducts, where measured in accordance with Section R403.3.3, shall be as follows:

1. Rough-in test: The total leakage shall be less than or equal to 4 cubic feet per minute (113.3 L/min) per 100 square feet (9.29 m²) of conditioned floor area where the air handler is installed at the time of the test. Where the air handler is not installed at the time of the test, the total leakage shall be less than or equal to 3 cubic feet per minute (85 L/min) per 100 square feet (9.29 m²) of conditioned floor area.
2. Postconstruction test: Total leakage shall be less than or equal to 4 cubic feet per minute (113.3 L/min) per 100 square feet (9.29 m²) of conditioned floor area.

❖ The pass/fail criteria for the tested duct leakage rate is more stringent if the rough-in test time is chosen. This is simply because it is probable that some of the ductwork will be disturbed during subsequent construction and, therefore, have a higher leakage rate than what was tested.

R403.3.5 Building cavities (Mandatory). Building framing cavities shall not be used as ducts or plenums.

❖ Building framing cavities shall not be used as ducts or plenums. Stud bays and other building cavities that are exposed to the differing outside temperatures cannot be used as supply air ducts. In addition, these spaces are limited to use for return air only because the negative pressures in the return air plenum with respect to surrounding spaces will decrease the likelihood of spreading smoke to other spaces via the plenum. In addition, for many of the same reasons that sealing (Section R403.2.2) is required, building cavities are a very inefficient means of distributing air.

R403.4 Mechanical system piping insulation (Mandatory). Mechanical system piping capable of carrying fluids above 105°F (41°C) or below 55°F (13°C) shall be insulated to a minimum of R-3.

❖ Heat losses during mechanical fluid distribution impact building energy use both in the energy required to make up for the lost heat and in the additional load that can be placed on the space-cooling system if the heat is released to air-conditioned space. These losses can be effectively limited by insulating the mechanical system piping that conveys fluids at extreme temperatures.

R403.4.1 Protection of piping insulation. Piping insulation exposed to weather shall be protected from damage, including that caused by sunlight, moisture, equipment maintenance and wind, and shall provide shielding from solar radiation that can cause degradation of the material. Adhesive tape shall not be permitted.

❖ Proper protection of piping insulation exposed to the weather elements is necessary to prevent damage, including that due to sunlight, moisture, equipment maintenance and wind.

R403.5 Service hot water systems. Energy conservation measures for service hot water systems shall be in accordance with Sections R403.5.1 through R403.5.4.

❖ A review of the definition of “Service water heating” in Chapter 2 is appropriate before applying these requirements. Any time the system is set up to circulate the water through it, the piping is required to be insulated as listed in Section R403.5.2.

R403.5.1 Heated water circulation and temperature maintenance systems (Mandatory). Heated water circulation systems shall be in accordance with Section R403.5.1.1. Heat trace temperature maintenance systems shall be in

accordance with Section R403.5.1.2. Automatic controls, temperature sensors and pumps shall be accessible. Manual controls shall be readily accessible.

❖ When the distribution piping is heated to maintain usage temperatures, such as in circulating hot water systems or systems using pipe heating cable, the system pump or heat trace cable must have conveniently located manual or automatic switches or other controls that can be set to optimize system operation or turn off the system during periods of reduced demand. The simplest of these devices is an automatic time clock. Notice, however, that the code will accept either a readily accessible manual switch or an automatic means to turn off the circulating pump.

R403.5.1.1 Circulation systems. Heated water circulation systems shall be provided with a circulation pump. The system return pipe shall be a dedicated return pipe or a cold water supply pipe. Gravity and thermo-syphon circulation systems shall be prohibited. Controls for circulating hot water system pumps shall start the pump based on the identification of a demand for hot water within the occupancy. The controls shall automatically turn off the pump when the water in the circulation loop is at the desired temperature and when there is no demand for hot water.

❖ Demand-activated circulation is an efficient energy conservation strategy, given that the code, the *International Plumbing Code*® (IPC®) and the IRC require that the hot water piping in automatic temperature maintenance systems in new buildings be insulated with pipe insulation. This means the water in the circulation loop will stay hot for a very long time—up to 45 minutes for 3/4-inch nominal pipe and up to 2 hours for 2-inch nominal pipe—even if the circulating pump is shut off. If this is the case, there is no reason to run the pump when the water is still hot and no reason to run the pump when no one is in the building or when no one is demanding hot water. The only time it makes sense to run the pump is shortly before hot water is needed, hence the requirement that the pump be controlled on-demand.

R403.5.1.2 Heat trace systems. Electric heat trace systems shall comply with IEEE 515.1 or UL 515. Controls for such systems shall automatically adjust the energy input to the heat tracing to maintain the desired water temperature in the piping in accordance with the times when heated water is used in the occupancy.

❖ The requirements for heat trace are partly to ensure that the systems can be operated in the most energy-

**TABLE R403.6.1
MECHANICAL VENTILATION SYSTEM FAN EFFICACY**

FAN LOCATION	AIR FLOW RATE MINIMUM (CFM)	MINIMUM EFFICACY (CFM/WATT)	AIR FLOW RATE MAXIMUM (CFM)
Range hoods	Any	2.8 cfm/watt	Any
In-line fan	Any	2.8 cfm/watt	Any
Bathroom, utility room	10	1.4 cfm/watt	< 90
Bathroom, utility room	90	2.8 cfm/watt	Any

For SI: 1 cfm = 28.3 L/min.